

INSTALLATION INSTRUCTIONS

FOR KIT #256155 & #256156

FOR RPH 8000, 10000, 12000, SERIES & HDP 8000, 10000

These tensioner kits are designed specifically for Ramsey Winch Models RPH 8000, 10000, 12000 & HDP 8000 & 10000. Kit #256155 for standard drum & #256156 for "Y" drum are configured for overwound and underwound applications. Winch removal may be necessary before kit installation.

INSTALLATION PROCEDURE

Disengage the winch clutch and free spool cable off the winch **except the last wrap**. Remove and discard the tie plate on the opposite side of the working cable. Install the tensioner assembly (#1) using existing tie plate bolts. Install roller up for overwound application (illustration #1) and roller down for underwound applications (illustration #2). Spacers (#2) may be required for some underwound applications for roller clearance. **If spacers are used, ½" longer bolts (must be Grade 8 Bolts, not included) must be used to mount winch.** Engage winch clutch and wind cable onto winch drum.

